
EXhibitt

SEST AVAILABLE COPY

GnackCenter and RefreshmentCenter **Programming Guide**





147 / 148 461 / 462 474 / 475 / 476 477 / 478 / 479

Copyright © 6-93


1470066




CRANE- National Vendors

THE MATRIX

We can start putting together all the things you've learned into a method to get around the programming procedures a little easier. You know how to find the detailed procedures in the tables, and how to start into and end them. After you get more familiar with some of the functions you might not want to work through those tables all the time, because you pretty well know what to do. This is when you can use the <u>MATRIXES</u>. Each matrix is a picture of the various tasks you can do within a function. Let's take a look at the PAYOUT matrix and find out what it's all about.



PAYOUT PROGRAMMING MATRIX



Page 18

PAYOUT A Single Quarter

STEP	ENTER THIS KEYSTROKE	AND THE DISPLAY INDICATES	COMMENTS
1	PAYOUT	PRYOUT	Payout mode entered.
2	•	SGL COIN	Enters individual coin payout sequence.
3	•	QUARTER	
4	Quickly press and release: ENTER ACTION O P T T TEST YEND	QUARTER	A single quarter is paid out
	Press and hold: N S ENTER ACTION OR TEST VENO	QUARTER	Quarters are paid out until key is released.
	CONTINUE	RERDY	Options: 1. Close monetary door. Press another 2. function switch. See advanced 3. programming section for other options.

PAYOUT A Single Dime

STEP	ENTER THIS	AND THE DISPLAY	COMMENTS
SIEP	KEYSTROKE	INDICATES	
1	PAYOUT	PRYOUT	Payout mode entered.
2	•	SGL COIN	Enters individual coin payout sequence.
. 3	•	QUARTER	
4	•	DIME	
5	Ouickly press and release: ENTER ACTION OP T T T	DIME	A single dime is paid out.
3	O Press and hold: S ENTER ACTION OR	DIME	Dimes are paid out until key is released.
6	CONTINUE	READY	Options: 1. Close monetary door. 2. Press another function switch. 3. See advanced programming section for other options.

First Edi

PAYOUT A Single Nickel

PATOUT A Single Nickel				
STEP	ENTER THIS KEYSTROKE	AND THE DISPLAY INDICATES	COMMENTS	
1	PAYOUT	PRYOUT	Payout mode entered.	
2	•	SGL COIN	Enters individual coin payout sequence.	
3	•	QUARTER		
4_	Until the following display is shown:	NICKEL		
5	Quickly press and release: BATER ACTION OP TEST VEND	UICKEL	A single nickel is paid out.	
	Press and hold: N S BITER ACTION OR TEST VENO	NICKEL	Nickels are paid out until key is released.	
6	CONTINUE	READY	Close monetary door. Press another function switch. See advanced programming section for other options.	

PAYOUT All Of The Quarters in Tube Inventory

PATOST			
STEP	ENTER THIS KEYSTROKE	AND THE DISPLAY INDICATES	COMMENTS
1 ·	PAYOUT	PRYOUT	Payout mode entered.
2	•	SGL COIN	
3	•	DUMP TUBE	Allows unloading of entire tube inventory.
4	•	QUARTER	Allows unloading of quarter tube.
5	ENTER	QUARTER	Controller pays out all quarters that it has in its tube inventory.
. 6	CONTINUE	READY	Options: 1. Close monetary door. 2. Press another function switch. 3. See advanced programming section for other options.

PAYOUT All Of The Dimes in Tube Inventory

STEP	ENTER THIS KEYSTROKE	AND THE DISPLAY INDICATES	COMMENTS
1	PAYOUT	PRYOUT	Payout mode entered.
2	•	SGL COIN	
3	•	DUMP TUBE	Allows unloading of entire tube inventory.
4	•	QUARTER	
5	•	DIME	Allows unloading of dime tube.
6	ENTER	DINE	Controller pays out all dimes that it has in its tube inventory.
7	CONTINUE	READY	Options: 1. Close monetary door. 2. Press another function switch. 3. See advanced programming section for other options.

PAYOUT All Of The Nickels In Tube Inventory

STEP	ENTER THIS KEYSTROKE	AND THE DISPLAY INDICATES	COMMENTS.
1	PAYOUT	PRYOUT	Payout mode entered.
2	•	SGL COIN	•
3	•	DUMP TUBE	Allows unloading of entire tube inventory.
4	•	QUARTER	ţ
5	Until the following display shows:	NICKEL	Allows unloading of nickel tube.
6	ENTER	NICKEL	Controller pays out all nickels that it has in its tube inventory.
7	CONTINUE	READY	Options: 1. Close monetary door. 2. Press another function switch. 3. See advanced programming section for other options.

PAYOUT All Of The Nickels In Tube Inventory

PATOUT All Of the tackets in 1220 income			
STEP	ENTER THIS KEYSTROKE	AND THE DISPLAY INDICATES	COMMENTS
1	PAYOUT	PRYOUT	Payout mode entered.
2	•	SGL COIM	
3	•	DUMP TUBE	
4	•	DUMP ALL	Allows unloading of entire tube inventory.
5	ENTER	DUMP ALL	Controller pays out all quarters, dimes, and nickels that it has in its tube inventory.
6	CONTINUE	READA	Options: 1. Close monetary door. 2. Press another function switch. 3. See advanced programming section for other options.